



Step 1. Flip shifter Arm so it points to the top of the trans. Find park. It has a long detent between park and reverse. Next ensure column shift is in park

Step 2. Install lower bracket and cable as shown in image 1  
Drill 1/8th hole into shifter arm ¼ inch below the original cable eye mount

Step 3. Install upper bracket as shown in pic 2. Ensure shifter linkage has some movement and is not tight.

Step 4. Install bolt through column as shown in pic 3. A bushing may be needed.

Step 5. Tighten all hardware and test the shifting. If binding do not force and re-adjust as necessary .